# AMACODER

# **One stop sourcing for Serialization**

## **Highlights**

- Integrated solution of coding line and <u>end to end</u>
  <u>IT-System</u> (from coding line up to governmental DB)
- Innovative mechanics and cloud based IT <u>Un-</u> <u>rivaled low investment</u> and <u>running cost</u> plus short delivery time
- Extremely <u>short coding line</u> (1 Meter incl. Labeler)
- Easy operation -> No experts required

## 



### System

Hicof combines the coding and labeling line with a comprehensive corporate, easy to operate, GxP compliant database to an **integrated solution**. This makes complex and expensive multilevel IT systems with multiple interfaces and data integrity issues obsolete. The Amacoder IT system allows the processing of all serialization data, supports related business processes and offers interfaces to business and governmental partners.

The coding line Amacoder uses an innovative box transport rationale, built in Swiss quality by deploying proven premium industrial components ensuring robust operation. The result is an <u>ultra-compact</u> <u>machine</u> (Including labeler only 1 meter long). Integration of Amacoders into existing packaging lines is easy.

Due to its creative mechanical design and use of groundbreaking IT technologies as e.g. cloud computing the Amacoder offers unrivaled **low investment and operational cost** as well as short delivery times.

Hicof – Swiss quality based on 18 years of experience and expertise in serialization.



# AMACODER

# **One stop sourcing for Serialization**

## **Technical specifications codingline Amacoder**

The Amacoder is offered in the following versions:

Functionality	FLEX	SPEED
Description	Full blown serialization and TE labeling machine, highly flexible	Full blown serialization and TE labeling machine, high speed
Machine width	1080 mm	1080 mm
Machine depth	1150 mm (1500 mm²)	1150 mm
Machine height	1650 mm	1650 mm
Box width	30 – 200 mm	30 – 200 mm
Box depth	55 – 300 mm	55 – 200 mm
Box height	15 – 150 mm	15 – 150 mm
Machine Speed	Up to 80 pcs/minute	Up to 150 pcs/minute

### **Amacoder IT deliverables**

Hierarchy	Functionality	Availabil- ity
<b>Level 1</b> : Line control	Printer, camera and labeler controller, PLC; machine settings (recipes)	Included
<b>Level 2</b> : Line Server	Mgt. of line serial data as serial numbers, rejects, sam- pling and number reconciliation; Batch record	Included
Level 3: Site & Corporate Server	Packaging order Mgt.; Master data Mgt.; Report genera- tor; Communication with MAH through private data hubs as TraceLink	Included
Level 4: MAH Server	Serial number generator; Communication with govern- mental agencies like EMVO	Optional
Interfaces	Standard interfaces to data hubs	Included
Interfaces	Customer specific interfaces	Optional
Services	Software updates and support	Included

### **Implementation Support**

Hicof AG offers documentation & support for validation/qualification (IQ-OQ-FAT-SAT) and training in form of standardizes packages. Additional support regarding business processes, legal require-ments and barcode technologies offers our mother company Vesdo AG.